




JBX RESORT APARTMENTS LIPNO

INSTRUCTIONS ON HOW TO USE THE SAFE (LOCATED IN THE CUPBOARD)

First locking of the safe

- open the safe door, on the inside of it is a red RESET button (1)
- press the red button, the display shows SET – Code (2)
- enter your own personal code (4–8 digits)
- in case of mistake, delete the digit with the ENTER button
- confirm the entered code by pressing the button with the  symbol, the display shows IN (code set) (3)
- close the door and turn the handle to the left
- the safe is now locked

Unlocking the safe

- enter your personal code (4–8 digits) and press the button with the key symbol – the display now shows OPEN (4)
- turn the handle to the right to open the door

Second and every next locking of the safe

- just close the door and turn the handle to the left

For emergency opening of the safe, please contact our central reception on + 420 381 255 090.

