



JBX RESORT AVENUE LIPNO

INSTRUCTIONS ON HOW TO USE THE SAFE

Locking of the safe

- enter your own personal code (4-6 digits)
- close the door, hold it closed and press #
- display shows CLOSE ●
- the safe is now locked

Unlocking the safe

- enter your own personal code (4-6 digits)
- display now shows OPEN ●
- the safe is now unlocked

Be careful. Safe always remembers the last code you have used. If you accidentally press two digits in row, it becomes new unique code.

If you need help, contact our central reception on + 420 381 255 090.

